

Pro XP, Pro R, Turbo R 2-4 Installation

1. Remove these two screws.

2. Guide the narrow end through the space between the intake box and the windshield.

Note: If you have a speaker position it between the intake and speaker.



3. Securely position the square cut out over the mounting tower on the plastic panel.

Note: Ensure the bottom edge is snugly resting on the interior of the frame

4. Reinstall the screws. Repeat on the other side.